



Replacing a door bracket in a P9000/P12000

1. Remove the 2 brass knobs by loosening with 5/64th allen key
2. Undo the brass nut around the gas knob with a 13/16ths wrench.
3. Remove the 8 (P12000 – 12) screws from the sides of the unit
4. Remove the bottom and top panels.
5. Remove the shroud from the main unit. Door must be unlatched to accomplish this.
6. Unscrew the 2 screws holding on the door latch bracket
7. Place the screws back into the holes and place the springs over the mount holes in the new bracket.
8. Raise the bracket up making sure the screws enter into the springs and mount into the holes in the bracket.
9. Screw in until the long flange on the bracket almost comes level with the front of the unit.
10. Put shroud back onto unit and screw on.
11. Replace top and bottom panels
12. Reconnect the gas knob with the brass nut. Remember to replace the gas plate.
13. Replace the brass knobs.