



Replacing the Oven valve on a Mediterranean/Caribbean Stove

- 1) Remove the top cooking grill. It should unsnap from the top sink.
- 2) Remove the top sink by unscrewing the 4 screws located on the inside of the sink. This will expose the burners
- 3) Undo the 2 smaller thermocouple nuts using an 8mm wrench
- 4) Undo the top copper line at the oven valve using a 13mm wrench
- 5) Undo the copper line at the brass fitting in the back using a 9/16" wrench. Make sure to brace the fitting with vice grips to avoid putting excess pressure on the fitting and/or the broiler.
- 6) Inside the oven loosen the brackets holding the oven probe in place. Then feed the oven probe and wire back through the hole to the top of the stove.
- 7) Loosen the screws holding the plate which holds the valve onto the manifold.
- 8) Remove the valve from the unit and place in a vice upside down. Remove the copper line using a 13mm wrench.
- 9) Place the new valve in the vice and reconnect the copper line to the underside hole. Make sure to use threadlocker.
10. Follow steps 1 through 8 in reverse to complete install.