




Cleaning a Top Burner Thermocouple in a Two Burner Drop In

- 1) Remove Grill and Large burner flame spreader
- 2) Undo 4 screws holding top on and remove sink
- 3) Locate the thermocouple connections for the burners at the valves
- 4) Gently twist them off and then re-attach them making sure they are fully mounted
- 5) Re-assemble the stove following steps 1 and 2 in reverse order

NOTE Do not kink the thermocouple as this may cause it to work improperly. Make all bends gradual.



Propane stove pictured