



Replacing the Burner Cup in a Cozy Cabin Heater

1. Undo the 2 screws holding the cap/flame spreader on the top of the base and remove.
2. Undo the 2 shoulder bolts holding the top shroud to the burner cup.
3. Remove the 4 screws holding the top shroud in the brass shroud and remove.
4. Undo the burner cup from the copper line using a 13mm wrench. Brace the burner cup with vice grips so that you don't bend the copper line.
5. Install the new burner cup using the old fittings. Make sure to use loctite or another thread sealant on the threads when tightening.
6. Check for leaks before re-assembling by putting soapy water on the connection and turning on the gas. Check for bubbles at the connection.
7. Re-assemble the base by following steps 1-3 in reverse order.